



## How to replace a tenkara rod segment or tenkara rod tip:

### Remove broken segment

1. Unscrew bottom cap from rod (counterclock-wise)



2. Expose rod segments through back of the rod.



3. Remove 3 tip segments as one set



### Replace broken segment with new one

4. Leaving the lillian (braid), the very tip of the rod, and tip of second segment protected inside the thicker third segment, insert 3 segment set into rod, tip first.



5. Make sure the top rod opening (opening away from handle) is closed to avoid pieces from slipping out.



6. Screw bottom cap on.

